Mounting instructions ekey dLine fingerprint (door handle)



ID356/742/0/709: Version 1, 2020-10-02








Property damage in the event of incorrect mounting and wiring: The system devices are operated

using electricity.

They could be destroyed if they are mounted and wired incorrectly. Mount and wire the system devices correctly before connecting the power.


NOTICE


These Mounting instructions are not subject to updating. We reserve the right to make technical modifications and change the product's appearance; any liability for errors and misprints is excluded.






5









4

